

LEMO VS Touch connectors' P/N

Plastic connectors 1P series		
LEMO Part Number (briefly)	Description	Touch Part Number (briefly)
PAG M02	1P2pin plug	1PTTN02
PAG M03	1P3pin plug	1PTTN03
PAG M04	1P4pin plug	1PTTN04
PAG M05	1P5pin plug	1PTTN05
PAG M06	1P6pin plug	1PTTN06
PAG M07	1P7pin plug	1PTTN07
PAG M08	1P8pin plug	1PTTN08
PAG M09	1P9pin plug	1PTTN09
PAG M10	1P10pin plug	1PTTN10
PAG M14	1P14pin plug	1PTTN14
PKG M02	1P2pin socket	1PSZN02
PKG M03	1P3pin socket	1PSZN03
PKG M04	1P4pin socket	1PSZN04
PKG M05	1P5pin socket	1PSZN05
PKG M06	1P6pin socket	1PSZN06
PKG M07	1P7pin socket	1PSZN07
PKG M08	1P8pin socket	1PSZN08
PKG M09	1P9pin socket	1PSZN09
PKG M10	1P10pin socket	1PSZN10
PKG M14	1P14pin socket	1PSZN14

Metal connectors 0B series		
LEMO Part Number	Description	Touch Part Number
FGG. 0B. 302	0B2pin plug	0BHTN02
FGG. 0B. 303	0B3pin plug	0BHTN03
FGG. 0B. 304	0B4pin plug	0BHTN04
FGG. 0B. 305	0B5pin plug	0BHTN05
FGG. 0B. 306	0B6pin plug	0BHTN06
FGG. 0B. 307	0B7pin plug	0BHTN07
FGG. 0B. 309	0B9pin plug	0BHTN09
FGA. 0B. 302	0B2pin plug two keys (alpha=30)	0BHTA02
FGA. 0B. 303	0B3pin plug two keys (alpha=30)	0BHTA03
FGA. 0B. 304	0B4pin plug two keys (alpha=30)	0BHTA04
FGA. 0B. 305	0B5pin plug two keys (alpha=30)	0BHTA05
FGA. 0B. 306	0B6pin plug two keys (alpha=30)	0BHTA06
FGA. 0B. 307	0B7pin plug two keys (alpha=30)	0BHTA07
FGA. 0B. 309	0B9pin plug two keys (alpha=30)	0BHTA09
FNG. 0B. 302	0B2pin plug (with lanyard release)	0BLTN02
FNG. 0B. 303	0B3pin plug (with lanyard release)	0BLTN03

FNG. OB. 304	OB4pin plug (with lanyard release)	OBLTN04
FNG. OB. 305	OB5pin plug (with lanyard release)	OBLTN05
FNG. OB. 306	OB6pin plug (with lanyard release)	OBLTN06
FNG. OB. 307	OB7pin plug (with lanyard release)	OBLTN07
FNG. OB. 309	OB9pin plug (with lanyard release)	OBLTN09
EGG. OB. 302	OB2pin socket	OBTZN02
EGG. OB. 303	OB3pin socket	OBTZN03
EGG. OB. 304	OB4pin socket	OBTZN04
EGG. OB. 305	OB5pin socket	OBTZN05
EGG. OB. 306	OB6pin socket	OBTZN06
EGG. OB. 307	OB7pin socket	OBTZN07
EGG. OB. 309	OB9pin socket	OBTZN09
EGA. OB. 302	OB2pin socket two keys(alpha=30)	OBTZA02
EGA. OB. 303	OB3pin socket two keys(alpha=30)	OBTZA03
EGA. OB. 304	OB4pin socket two keys(alpha=30)	OBTZA04
EGA. OB. 305	OB5pin socket two keys(alpha=30)	OBTZA05
EGA. OB. 306	OB6pin socket two keys(alpha=30)	OBTZA06
EGA. OB. 307	OB7pin socket two keys(alpha=30)	OBTZA07
EGA. OB. 309	OB9pin socket two keys(alpha=30)	OBTZA09
EEG. OB. 302	OB2pin socket	OBPZN02
EEG. OB. 303	OB3pin socket	OBPZN03
EEG. OB. 304	OB4pin socket	OBPZN04
EEG. OB. 305	OB5pin socket	OBPZN05
EEG. OB. 306	OB6pin socket	OBPZN06
EEG. OB. 307	OB7pin socket	OBPZN07
EEG. OB. 309	OB9pin socket	OBPZN09
EPG. OB. 302	OB2pin elbow socket	OBNZN02
EPG. OB. 303	OB3pin elbow socket	OBNZN03
EPG. OB. 304	OB4pin elbow socket	OBNZN04
EPG. OB. 305	OB5pin elbow socket	OBNZN05
EPG. OB. 306	OB6pin elbow socket	OBNZN06
EPG. OB. 307	OB7pin elbow socket	OBNZN07
EXG. OB. 302	OB2pin elbow socket with two nuts	OBWZN02
EXG. OB. 303	OB3pin elbow socket with two nuts	OBWZN03
EXG. OB. 304	OB4pin elbow socket with two nuts	OBWZN04
EXG. OB. 305	OB5pin elbow socket with two nuts	OBWZN05
EXG. OB. 306	OB6pin elbow socket with two nuts	OBWZN06
EXG. OB. 307	OB7pin elbow socket with two nuts	OBWZN07
PHG. OB. 302	OB2pin free socket	OBHZN02
PHG. OB. 303	OB3pin free socket	OBHZN03
PHG. OB. 304	OB4pin free socket	OBHZN04
PHG. OB. 305	OB5pin free socket	OBHZN05
PHG. OB. 306	OB6pin free socket	OBHZN06
PHG. OB. 307	OB7pin free socket	OBHZN07
PHG. OB. 309	OB9pin free socket	OBHZN09

Metal connectors 1B series

LEMO Part Number	Description	Touch Part Number
FGG. 1B. 302	1B2pin plug	1BHTN02
FGG. 1B. 303	1B3pin plug	1BHTN03
FGG. 1B. 304	1B4pin plug	1BHTN04
FGG. 1B. 305	1B5pin plug	1BHTN05
FGG. 1B. 306	1B6pin plug	1BHTN06
FGG. 1B. 307	1B7pin plug	1BHTN07
FGG. 1B. 308	1B8pin plug	1BHTN08
FGG. 1B. 310	1B10pin plug	1BHTN10
FGG. 1B. 314	1B14pin plug	1BHTN14
FGA. 1B. 302	1B2pin plug two keys(alpha=30)	1BHTA02
FGA. 1B. 303	1B3pin plug two keys(alpha=30)	1BHTA03
FGA. 1B. 304	1B4pin plug two keys(alpha=30)	1BHTA04
FGA. 1B. 305	1B5pin plug two keys(alpha=30)	1BHTA05
FGA. 1B. 306	1B6pin plug two keys(alpha=30)	1BHTA06
FGA. 1B. 307	1B7pin plug two keys(alpha=30)	1BHTA07
FGA. 1B. 308	1B8pin plug two keys(alpha=30)	1BHTA08
FGA. 1B. 310	1B10pin plug two keys(alpha=30)	1BHTA10
FGA. 1B. 314	1B14pin plug two keys(alpha=30)	1BHTA14
EGG. 1B. 302	1B2pin socket	1BTZN02
EGG. 1B. 303	1B3pin socket	1BTZN03
EGG. 1B. 304	1B4pin socket	1BTZN04
EGG. 1B. 305	1B5pin socket	1BTZN05
EGG. 1B. 306	1B6pin socket	1BTZN06
EGG. 1B. 307	1B7pin socket	1BTZN07
EGG. 1B. 308	1B8pin socket	1BTZN08
EGG. 1B. 310	1B10pin socket	1BTZN10
EGG. 1B. 314	1B14pin socket	1BTZN14
EEG. 1B. 302	1B2pin socket	1BPZN02
EEG. 1B. 303	1B3pin socket	1BPZN03
EEG. 1B. 304	1B4pin socket	1BPZN04
EEG. 1B. 305	1B5pin socket	1BPZN05
EEG. 1B. 306	1B6pin socket	1BPZN06
EEG. 1B. 307	1B7pin socket	1BPZN07
EEG. 1B. 308	1B8pin socket	1BPZN08
EEG. 1B. 310	1B10pin socket	1BPZN10
EEG. 1B. 314	1B14pin socket	1BPZN14
ECG. 1B. 302	1B2pin socket with two nuts	1BSZN02
ECG. 1B. 303	1B3pin socket with two nuts	1BSZN03
ECG. 1B. 304	1B4pin socket with two nuts	1BSZN04
ECG. 1B. 305	1B5pin socket with two nuts	1BSZN05
ECG. 1B. 306	1B6pin socket with two nuts	1BSZN06
ECG. 1B. 307	1B7pin socket with two nuts	1BSZN07
ECG. 1B. 308	1B8pin socket with two nuts	1BSZN08
ECG. 1B. 310	1B10pin socket with two nuts	1BSZN10
ECG. 1B. 314	1B14pin socket with two nuts	1BSZN14

EGA. 1B. 302	1B2pin socket two keys(alpha=30)	1BTZA02
EGA. 1B. 303	1B3pin socket two keys(alpha=30)	1BTZA03
EGA. 1B. 304	1B4pin socket two keys(alpha=30)	1BTZA04
EGA. 1B. 305	1B52pin socket two keys(alpha=30)	1BTZA05
EGA. 1B. 306	1B6pin socket two keys(alpha=30)	1BTZA06
EGA. 1B. 307	1B7pin socket two keys(alpha=30)	1BTZA07
EGA. 1B. 308	1B8pin socket two keys(alpha=30)	1BTZA08
EGA. 1B. 310	1B10pin socket two keys(alpha=30)	1BTZA10
EGA. 1B. 314	1B14pin socket two keys(alpha=30)	1BTZA14
ECA. 1B. 302	1B2pin socket with two nuts and two keys	1BSZA02
ECA. 1B. 303	1B3pin socket with two nuts and two keys	1BSZA03
ECA. 1B. 304	1B4pin socket with two nuts and two keys	1BSZA04
ECA. 1B. 305	1B5pin socket with two nuts and two keys	1BSZA05
ECA. 1B. 306	1B6pin socket with two nuts and two keys	1BSZA06
ECA. 1B. 307	1B7pin socket with two nuts and two keys	1BSZA07
ECA. 1B. 308	1B8pin socket with two nuts and two keys	1BSZA08
ECA. 1B. 310	1B10pin socket with two nuts and two keys	1BSZA10
ECA. 1B. 314	1B14pin socket with two nuts and two keys	1BSZA14
HGG. 1B. 302	1B2pin socket (watertight or vacuumtight)	1BFZN02
HGG. 1B. 303	1B3pin socket (watertight or vacuumtight)	1BFZN03
HGG. 1B. 304	1B4pin socket (watertight or vacuumtight)	1BFZN04
HGG. 1B. 305	1B5pin socket (watertight or vacuumtight)	1BFZN05
HGG. 1B. 306	1B6pin socket (watertight or vacuumtight)	1BFZN06
HGG. 1B. 307	1B7pin socket (watertight or vacuumtight)	1BFZN07
HGG. 1B. 308	1B8pin socket (watertight or vacuumtight)	1BFZN08
HGG. 1B. 310	1B10pin socket (watertight or vacuumtight)	1BFZN10
HGG. 1B. 314	1B14pin socket (watertight or vacuumtight)	1BFZN14
HGA. 1B. 302	1B2pin socket with two keys (watertight or vacuumtight)	1BFZA02
HGA. 1B. 303	1B3pin socket with two keys (watertight or vacuumtight)	1BFZA03
HGA. 1B. 304	1B4pin socket with two keys (watertight or vacuumtight)	1BFZA04
HGA. 1B. 305	1B5pin socket with two keys (watertight or vacuumtight)	1BFZA05
HGA. 1B. 306	1B6pin socket with two keys (watertight or vacuumtight)	1BFZA06
HGA. 1B. 307	1B7pin socket with two keys (watertight or vacuumtight)	1BFZA07
HGA. 1B. 308	1B8pin socket with two keys (watertight or vacuumtight)	1BFZA08
HGA. 1B. 310	1B10pin socket with two keys (watertight or vacuumtight)	1BFZA10
HGA. 1B. 314	1B14pin socket with two keys (watertight or vacuumtight)	1BFZA14
PHG. 1B. 302	1B2pin free socket	1BHZN02
PHG. 1B. 303	1B3pin free socket	1BHZN03
PHG. 1B. 304	1B4pin free socket	1BHZN04
PHG. 1B. 305	1B5pin free socket	1BHZN05
PHG. 1B. 306	1B6pin free socket	1BHZN06

PHG. 1B. 307	1B7pin free socket	1BHZN07
PHG. 1B. 308	1B8pin free socket	1BHZN08
PHG. 1B. 310	1B10pin free socket	1BHZN10
PHG. 1B. 314	1B14pin free socket	1BHZN14
EPG. 1B. 302	1B2pin elbow socket	1BNZN02
EPG. 1B. 303	1B3pin elbow socket	1BNZN03
EPG. 1B. 304	1B4pin elbow socket	1BNZN04
EPG. 1B. 305	1B5pin elbow socket	1BNZN05
EPG. 1B. 306	1B6pin elbow socket	1BNZN06
EPG. 1B. 307	1B7pin elbow socket	1BNZN07
EPG. 1B. 308	1B8pin elbow socket	1BNZN08
EXG. 1B. 302	1B2pin elbow socket with two nuts	1BWZN02
EXG. 1B. 303	1B3pin elbow socket with two nuts	1BWZN03
EXG. 1B. 304	1B4pin elbow socket with two nuts	1BWZN04
EXG. 1B. 305	1B5pin elbow socket with two nuts	1BWZN05
EXG. 1B. 306	1B6pin elbow socket with two nuts	1BWZN06
EXG. 1B. 307	1B7pin elbow socket with two nuts	1BWZN07
EXG. 1B. 308	1B8pin elbow socket with two nuts	1BWZN08

Metal connectors 2B series

LEMO Part Number	Description	Touch Part Number
FGG. 2B. 302	2B2pin plug	2BHTN02
FGG. 2B. 303	2B3pin plug	2BHTN03
FGG. 2B. 304	2B4pin plug	2BHTN04
FGG. 2B. 306	2B6pin plug	2BHTN06
FGG. 2B. 308	2B8pin plug	2BHTN08
FGG. 2B. 310	2B10pin plug	2BHTN10
FGG. 2B. 312	2B12pin plug	2BHTN12
FGG. 2B. 314	2B14pin plug	2BHTN14
FGG. 2B. 316	2B16pin plug	2BHTN16
FGG. 2B. 319	2B19pin plug	2BHTN19
FGG. 2B. 326	2B26pin plug	2BHTN26
FGA. 2B. 302	2B2pin plug two keys	2BHTA02
FGA. 2B. 303	2B3pin plug two keys	2BHTA03
FGA. 2B. 304	2B4pin plug two keys	2BHTA04
FGA. 2B. 306	2B6pin plug two keys	2BHTA06
FGA. 2B. 308	2B8pin plug two keys	2BHTA08
FGA. 2B. 310	2B10pin plug two keys	2BHTA10
FGA. 2B. 312	2B12pin plug two keys	2BHTA12
FGA. 2B. 314	2B14pin plug two keys	2BHTA14
FGA. 2B. 316	2B16pin plug two keys	2BHTA16
FGA. 2B. 319	2B19pin plug two keys	2BHTA19
FGA. 2B. 326	2B26pin plug two keys	2BHTA26
FAG. 2B. 302	2B2pin fixed plug	2BGTN02
FAG. 2B. 303	2B3pin fixed plug	2BGTN03
FAG. 2B. 304	2B4pin fixed plug	2BGTN04

FAG. 2B. 306	2B6pin fixed plug	2BGTN06
FAG. 2B. 308	2B8pin fixed plug	2BGTN08
FAG. 2B. 310	2B10pin fixed plug	2BGTN10
FAG. 2B. 312	2B12pin fixed plug	2BGTN12
FAG. 2B. 314	2B14pin fixed plug	2BGTN14
FAG. 2B. 316	2B16pin fixed plug	2BGTN16
FAG. 2B. 319	2B19pin fixed plug	2BGTN19
FAG. 2B. 326	2B26pin fixed plug	2BGTN26
EGG. 2B. 302	2B2pin socket	2BTZN02
EGG. 2B. 303	2B3pin socket	2BTZN03
EGG. 2B. 304	2B4pin socket	2BTZN04
EGG. 2B. 306	2B6pin socket	2BTZN06
EGG. 2B. 308	2B8pin socket	2BTZN08
EGG. 2B. 310	2B10pin socket	2BTZN10
EGG. 2B. 312	2B12pin socket	2BTZN12
EGG. 2B. 314	2B14pin socket	2BTZN14
EGG. 2B. 316	2B16pin socket	2BTZN16
EGG. 2B. 319	2B19pin socket	2BTZN19
EGG. 2B. 326	2B26pin socket	2BTZN26
EGA. 2B. 302	2B2pin socket two keys	2BTZA02
EGA. 2B. 303	2B3pin socket two keys	2BTZA03
EGA. 2B. 304	2B4pin socket two keys	2BTZA04
EGA. 2B. 306	2B6pin socket two keys	2BTZA06
EGA. 2B. 308	2B8pin socket two keys	2BTZA08
EGA. 2B. 310	2B10pin socket two keys	2BTZA10
EGA. 2B. 312	2B12pin socket two keys	2BTZA12
EGA. 2B. 314	2B14pin socket two keys	2BTZA14
EGA. 2B. 316	2B16pin socket two keys	2BTZA16
EGA. 2B. 319	2B19pin socket two keys	2BTZA19
EGA. 2B. 326	2B26pin socket two keys	2BTZA26
PHG. 2B. 302	2B2pin free socket	2BHZN02
PHG. 2B. 303	2B3pin free socket	2BHZN03
PHG. 2B. 304	2B4pin free socket	2BHZN04
PHG. 2B. 306	2B6pin free socket	2BHZN06
PHG. 2B. 308	2B8pin free socket	2BHZN08
PHG. 2B. 310	2B10pin free socket	2BHZN10
PHG. 2B. 312	2B12pin free socket	2BHZN12
PHG. 2B. 314	2B14pin free socket	2BHZN14

Metal connectors 3B series		
LEMO Part Number	Description	Touch Part Number
FGG. 3B. 303	3B3pin plug	3BHTN03
FGG. 3B. 304	3B4pin plug	3BHTN04
FGG. 3B. 305	3B5pin plug	3BHTN05
FGG. 3B. 312	3B12pin plug	3BHTN12

FGG. 3B. 314	3B14pin plug	3BHTN14
FGG. 3B. 316	3B16pin plug	3BHTN16
FGG. 3B. 318	3B18pin plug	3BHTN18
FGG. 3B. 320	3B20pin plug	3BHTN20
FGG. 3B. 321	3B21pin plug	3BHTN21
EGG. 3B. 303	3B3pin socket	3BTZN03
EGG. 3B. 304	3B4pin socket	3BTZN04
EGG. 3B. 305	3B5pin socket	3BTZN05
EGG. 3B. 312	3B12pin socket	3BTZN12
EGG. 3B. 314	3B14pin socket	3BTZN14
EGG. 3B. 316	3B16pin socket	3BTZN16
EGG. 3B. 318	3B18pin socket	3BTZN18
EGG. 3B. 320	3B20pin socket	3BTZN20
EGG. 3B. 321	3B21pin socket	3BTZN21
FAG. 3B. 303	3B3pin fixed plug	3BGTN03
FAG. 3B. 304	3B4pin fixed plug	3BGTN04
FAG. 3B. 305	3B5pin fixed plug	3BGTN05
FAG. 3B. 312	3B12pin fixed plug	3BGTN12
FAG. 3B. 314	3B14pin fixed plug	3BGTN14
FAG. 3B. 318	3B16pin fixed plug	3BGTN18
FAG. 3B. 320	3B18pin fixed plug	3BGTN20
FAG. 3B. 321	3B21pin fixed plug	3BGTN21

Watertight connectors OK series		
LEMO Part Number	Description	Touch Part Number
FGG. OK. 302	OK2pin plug	OKHTN02
FGG. OK. 303	OK3pin plug	OKHTN03
FGG. OK. 304	OK4pin plug	OKHTN04
FGG. OK. 305	OK5pin plug	OKHTN05
FGG. OK. 306	OK6pin plug	OKHTN06
FGG. OK. 307	OK7pin plug	OKHTN07
FGG. OK. 309	OK9pin plug	OKHTN09
EGG. OK. 302	OK2pin socket	OKTZN02
EGG. OK. 303	OK3pin socket	OKTZN03
EGG. OK. 304	OK4pin socket	OKTZN04
EGG. OK. 305	OK5pin socket	OKTZN05
EGG. OK. 306	OK6pin socket	OKTZN06
EGG. OK. 307	OK7pin socket	OKTZN07
EGG. OK. 309	OK9pin socket	OKTZN09
EEG. OK. 302	OK2pin socket	OKPZN02
EEG. OK. 303	OK3pin socket	OKPZN03
EEG. OK. 304	OK4pin socket	OKPZN04
EEG. OK. 305	OK5pin socket	OKPZN05
EEG. OK. 306	OK6pin socket	OKPZN06
EEG. OK. 307	OK7pin socket	OKPZN07
EEG. OK. 309	OK9pin socket	OKPZN09

PHG. OK. 302	0K2pin free socket	OKHZN02
PHG. OK. 303	0K3pin free socket	OKHZN03
PHG. OK. 304	0K4pin free socket	OKHZN04
PHG. OK. 305	0K5pin free socket	OKHZN05
PHG. OK. 306	0K6pin free socket	OKHZN06
PHG. OK. 307	0K7pin free socket	OKHZN07
PHG. OK. 309	0K9pin free socket	OKHZN09

Watertight connectors 1K series		
LEMO Part Number	Description	Touch Part Number
FGG. 1K. 302	1K2pin plug	1KHTN02
FGG. 1K. 303	1K3pin plug	1KHTN03
FGG. 1K. 304	1K4pin plug	1KHTN04
FGG. 1K. 305	1K5pin plug	1KHTN05
FGG. 1K. 306	1K6pin plug	1KHTN06
FGG. 1K. 307	1K7pin plug	1KHTN07
FGG. 1K. 308	1K8pin plug	1KHTN08
FGG. 1K. 310	1K10pin plug	1KHTN10
FGG. 1K. 314	1K14pin plug	1KHTN14
EGG. 1K. 302	1K2pin socket	1KTZN02
EGG. 1K. 303	1K3pin socket	1KTZN03
EGG. 1K. 304	1K4pin socket	1KTZN04
EGG. 1K. 305	1K5pin socket	1KTZN05
EGG. 1K. 306	1K6pin socket	1KTZN06
EGG. 1K. 307	1K7pin socket	1KTZN07
EGG. 1K. 308	1K8pin socket	1KTZN08
EGG. 1K. 310	1K10pin socket	1KTZN10
EGG. 1K. 314	1K14pin socket	1KTZN14
EEG. 1K. 302	1K2pin socket	1KPZN02
EEG. 1K. 303	1K3pin socket	1KPZN03
EEG. 1K. 304	1K4pin socket	1KPZN04
EEG. 1K. 305	1K5pin socket	1KPZN05
EEG. 1K. 306	1K6pin socket	1KPZN06
EEG. 1K. 307	1K7pin socket	1KPZN07
EEG. 1K. 308	1K8pin socket	1KPZN08
EEG. 1K. 310	1K10pin socket	1KPZN10
EEG. 1K. 314	1K14pin socket	1KPZN14

Watertight connectors 2K series		
LEMO Part Number	Description	Touch Part Number
FGG. 2K. 302	2K2pin plug	2KHTN02
FGG. 2K. 303	2K3pin plug	2KHTN03
FGG. 2K. 304	2K4pin plug	2KHTN04
FGG. 2K. 306	2K6pin plug	2KHTN06
FGG. 2K. 308	2K8pin plug	2KHTN08

FGG. 2K. 310	2K10pin plug	2KHTN10
FGG. 2K. 312	2K12pin plug	2KHTN12
FGG. 2K. 314	2K14pin plug	2KHTN14
FGG. 2K. 316	2K16pin plug	2KHTN16
FGG. 2K. 319	2K19pin plug	2KHTN19
FGG. 2K. 326	2K26pin plug	2KHTN26
EGG. 2K. 302	2K2pin socket	2KTZN02
EGG. 2K. 303	2K3pin socket	2KTZN03
EGG. 2K. 304	2K4pin socket	2KTZN04
EGG. 2K. 306	2K6pin socket	2KTZN06
EGG. 2K. 308	2K8pin socket	2KTZN08
EGG. 2K. 310	2K10pin socket	2KTZN10
EGG. 2K. 312	2K12pin socket	2KTZN12
EGG. 2K. 314	2K14pin socket	2KTZN14
EGG. 2K. 316	2K16pin socket	2KTZN16
EGG. 2K. 319	2K19pin socket	2KTZN19
EGG. 2K. 326	2K26pin socket	2KTZN26
EEG. 2K. 302	2K2pin socket	2KPZN02
EEG. 2K. 303	2K3pin socket	2KPZN03
EEG. 2K. 304	2K4pin socket	2KPZN04
EEG. 2K. 306	2K6pin socket	2KPZN06
EEG. 2K. 308	2K8pin socket	2KPZN08
EEG. 2K. 310	2K10pin socket	2KPZN10
EEG. 2K. 312	2K12pin socket	2KPZN12
EEG. 2K. 314	2K14pin socket	2KPZN14
EEG. 2K. 316	2K16pin socket	2KPZN16
EEG. 2K. 319	2K19pin socket	2KPZN19
EEG. 2K. 326	2K26pin socket	2KPZN26

Metal connectors OS series		
LEMO Part Number	Description	Touch Part Number
FFA. OS. 302	0S2pin plug	0SHTN02
FFA. OS. 303	0S3pin plug	0SHTN03
FFA. OS. 304	0S4pin plug	0SHTN04
ERA. OS. 302	0S2pin socket	0STZN02
ERA. OS. 303	0S3pin socket	0STZN03
ERA. OS. 304	0S4pin socket	0STZN04
PCA. OS. 302	0S2pin free socket	0SHZN02
PCA. OS. 303	0S3pin free socket	0SHZN03
PCA. OS. 304	0S4pin free socket	0SHZN04
FLA. OS. 302	0S2pin elbow plug	0SWTN02
FLA. OS. 303	0S3pin elbow plug	0SWTN03
FLA. OS. 304	0S4pin elbow plug	0SWTN04
ERD. OS. 302	0S2pin socket with two nuts	0SSZN02
ERD. OS. 303	0S3pin socket with two nuts	0SSZN03
ERD. OS. 304	0S4pin socket with two nuts	0SSZN04

EPL. OS. 302	0S2pin elbow socket	0SNZN02
EPL. OS. 303	0S3pin elbow socket	0SNZN03
EPL. OS. 304	0S4pin elbow socket	0SNZN04
EXP. OS. 302	0S2pin elbow socket with two nuts	0SWZN02
EXP. OS. 303	0S3pin elbow socket with two nuts	0SWZN03
EXP. OS. 304	0S4pin elbow socket with two nuts	0SWZN04

Metal connectors 1S series		
LEMO Part Number	Description	Touch Part Number
FFA. 1S. 303	1S3pin plug	1SHTN03
FFA. 1S. 304	1S4pin plug	1SHTN04
FFA. 1S. 305	1S5pin plug	1SHTN05
FFA. 1S. 306	1S6pin plug	1SHTN06
ERA. 1S. 303	1S3pin socket	1STZN03
ERA. 1S. 304	1S4pin socket	1STZN04
ERA. 1S. 305	1S5pin socket	1STZN05
ERA. 1S. 306	1S6pin socket	1STZN06
PCA. 1S. 303	1S3pin free socket	1SHZN03
PCA. 1S. 304	1S4pin free socket	1SHZN04
PCA. 1S. 305	1S5pin free socket	1SHZN05
PCA. 1S. 306	1S6pin free socket	1SHZN06

Metal connectors 2E series		
LEMO Part Number	Description	Touch Part Number
FFA. 2C. 302	2E2pin plug	2ETTN02
FFA. 2C. 303	2E3pin plug	2ETTN03
FFA. 2C. 304	2E4pin plug	2ETTN04
FFA. 2C. 305	2E5pin plug	2ETTN05
FFA. 2C. 306	2E6pin plug	2ETTN06
ERY. 2C. 302	2E2pin socket	2EDZN02
ERY. 2C. 303	2E3pin socket	2EDZN03
ERY. 2C. 304	2E4pin socket	2EDZN04
ERY. 2C. 305	2E5pin socket	2EDZN05
ERY. 2C. 306	2E6pin socket	2EDZN06